

## | Manual Cube20 BN-P

- | Description
- | Installation
- | Startup
- | Diagnostics
- | Technical Data

## Publisher's Note

Instruction manual for Cube20 BN-P DP-V1 DI8 (Article Number: 56001)

Version 3.2

Edition 11\_10 EN

Article Number 56001

Murrelektronik GmbH

Falkenstrasse 3

D-71570 Oppenweiler

Phone +49 (0) 71 91 47-0

Fax +49 (0) 71 91 47-130

[info@murrelektronik.de](mailto:info@murrelektronik.de)

## Service and Support

**Website:**

[www.murrelektronik.com](http://www.murrelektronik.com)

**In addition, our Customer Service Center (CSC) will be glad to assist you:**

Our Customer Service Center can support you throughout your project in the planning and conception of customer applications, configuration, installation, and startup. We also offer competent consulting or – in more complex cases – we even provide direct onsite support.

The Customer Service Center provides support tools. It performs measurements for fieldbus systems, such as PROFIBUS DP, DeviceNet, CANopen, and AS interface, as well as energy, heat, and EMC measurements.

Our coworkers at the Customer Service Center provide their competence, know-how, and years of experience. They are knowledgeable about hardware and software, and compatibility with products made by various manufacturers.

**You can contact the Customer Service Center at**

**Phone +49 (0) 71 91 47-424**

**or by email at [csc@murrelektronik.de](mailto:csc@murrelektronik.de)**

## About the User Manual and its Structure

### Bus Manual:

General explanations and functions for each bus.

On this subject, please click on the links to the next page.

### System Manuals:

Describe the system in general and give an overview about the products, accessories and documentation.

Art. No.	Designation
56030	Cube 20 System

[www.murrelektronik.com](http://www.murrelektronik.com)

### Product Manuals:

Describe product-specific features.

Art. No.	Designation
56001	Cube20 BN-P DI8
56005	Cube20 BN-E DI8
56006	Cube20 BN-PNIO DI8
56035	Cube20 Expansions

[www.murrelektronik.com](http://www.murrelektronik.com)

The following link will provide you with more information on the bus system, as well as the standards and specifications on which it is based:



# Important Information

## Minimum Basic Knowledge Requirements

This manual contains general information on the system and the product. For more details, refer to the bus manuals (see page **Fehler! Textmarke nicht definiert.**).

To understand this manual, you need to know about automation systems.

## Symbols and Icons

This manual contains information and instructions you must comply with in order to maintain safety and avoid personal injury or damage to property. They are identified as follows:



**Notes indicate important information.**



**Warnings contain information that, if you ignore this information, may cause damage to equipment or other assets or, if you fail to comply with safety precautions, may constitute a danger to the user's health and life.**



**These instructions are recommendations issued by Murrelektronik.**

# Table of Contents

Publisher's Note .....	2
Service and Support .....	3
About the User Manual and its Structure .....	4
Important Information .....	6
Table of Contents .....	7
1 Description of the Cube20 BN-P DP-V1 DI8 Art. No. 56001 .....	9
2 Installation .....	10
2.1 Mounting .....	10
2.2 Overview of Connections Cube20 BN-P DI8 Art. No. 56001 .....	11
3 Startup .....	12
3.1 Terminating PROFIBUS Segments .....	12
3.2 Assigning and Setting the PROFIBUS Address .....	12
3.3 GSD File .....	12
3.4 Baud Rates .....	13
3.5 Configuration and Parameterization .....	14
3.5.1 Example :Configuration of a Cube20 system with Simatic Step7® .....	15
3.5.2 Cube20 BN-P DP-V1 DI8 Art. No. 56001 .....	18
3.5.3 Cube20/67 Interface, Art. No. 56140 .....	21
3.5.4 Modules and Slots .....	22
3.6 I/O - Data Cube20 BN-P DP-V1 DI8 Art. No. 56001 .....	24
4 Diagnostics .....	25
4.1 LED Indicators .....	25
4.1.1 Significance of the States of the "Bus Run" LED .....	25
4.1.2 Significance of the States of the "Cfg F" LED .....	26
4.1.3 Displays for the Supply Voltage at the Terminals .....	27
4.1.4 Diagnostics Overview .....	27
4.2 Diagnostics via the Fieldbus .....	28
4.2.1 Standard Diagnostic Information Format .....	29

4.2.2 Identification-Related Diagnostic .....	32
4.2.3 Module Status Diagnostic.....	33
4.2.4 Channel-Related Diagnostic.....	35
4.3 Troubleshooting.....	37
5 DPV1 Support Cube20 BN-P DP-V1 DI8 Art. No. 56001.....	39
5.1 Supported DPV1 Indices.....	39
5.1.1 Index 10 "Machine Options Management" .....	39
5.1.2 Index 12 "BusControl" .....	42
5.1.3 Index 13 "Machine Options Management Configuration Test" .....	42
5.1.4 Index 255 "Identification and Maintenance" (I&M) .....	43
6 Machine Options Management (MOM) .....	49
6.1 Module Selection and Setting a Configuration.....	49
6.2 Configuration Test.....	51
6.3 Module Change .....	52
7 Usable Modules .....	54
7.1 Cube20 Modules .....	54
7.2 Cube67 Modules .....	54
7.3 Cube67+ Modules .....	54
8 Technical Data Cube20 BN-P DP-V1 DI8 Art. No. 56001.....	55
Accessories.....	57
Glossary.....	58
Legal Provisions.....	61



# 1 Description of the Cube20 BN-P DP-V1 DI8 Art. No. 56001

The Cube20 system is a modular I/O system with IP20 protection for decentralized collection and control of digital and analog process variables. It consists of a fieldbus specific bus node and I/O modules that are independent of the fieldbus and are connected to the bus node via an internal system connection. Galvanic separation between the supply of the system supply and the sensor supply has to be provided.

In order to maximize electromagnetic compatibility, we advise you to ensure galvanic separation.




Fig. 1: Typical system structure with galvanic separation

The illustration above shows a typical Cube20 system structure with digital inputs and outputs (DI/DO) and analog inputs and outputs (AI/AO).

Furthermore, it shows PROFIBUS, I/O area, and I/O supply as well as the supply of the system electronics are galvanically separated. The internal electronics of the digital input/output modules are supplied by the system cable. The internal electronics of the analog input/output modules are supplied via the input/output supply voltage.



## Information on the analog I/O modules.

The I/O supply voltage must always be connected, otherwise communication via the internal system connection is interrupted, starting from the analog module that is not supplied.



### Application Notes

The bus node "Cube20 BN-P DP-V1 DI8" described here is the successor to the "Cube20 BN-P DI8" that also bears Article Number 56001. Install the GDS file MUR20B3D.\* in order to obtain full functionality. The file can also be used in existing systems as a substitute for the "Cube20 BN-P DI8" with GSD file MURR0B3D.\*. In this case, the extended functions of the Cube20 BN-P DP-V1 DI8 are not available.

## 2 Installation

### 2.1 Mounting



For general information on mounting, please see the Cube20 system manual Art. No. 56030.

## 2.2 Overview of Connections Cube20 BN-P DI8 Art. No. 56001




Fig. 2: Overview of Connections Cube20 BN-P DP-V1 DI8 Art. No. 56001



We recommend use of our common terminal block Art. No. 56109.

For further information, please refer to the common terminal block instruction manual.

## 3 Startup

### 3.1 Terminating PROFIBUS Segments

A terminating resistor is required at the beginning and at the end of the PROFIBUS segment. The terminating resistors must be powered in order to guarantee a physically clean signal level. A maximum of 16 users may be connected to the PROFIBUS segment.

### 3.2 Assigning and Setting the PROFIBUS Address

The PROFIBUS address is set by means of two rotary switches directly on the Cube20. Values are permitted between 0 and 99. Usually, a DP Master assigns the addresses 0 to 2. Therefore, we recommend setting the addresses for Cube20 starting with address 3.



**The address setting is read in once after the power supply is connected. A change of address only becomes effective, therefore, when the module power supply is reset. When the address is assigned, make sure you provide each PROFIBUS device with a unique individual address.**

### 3.3 GSD File

The equipment described in this manual requires a GSD file

MURR20B3D.\* or MURR0B3D.\* in order to be operable.

The file suffix indicates the language version. GSD files are available in six different languages.

Language	File Suffix	Language	File Suffix
Default = English	*.gsd	French	*.gsf
English	*.gse	Italian	*.gsi
German	*.gsg	Portuguese	*.gsp
Spanish	*.gss		

Tab. 1: GSD File Suffixes



The GSD file is downloadable from the Murrelektronik website:

<http://www.murrelektronik.com/>



The software features described in this manual can only be activated by installing GDS (DDB) file MUR20B3D.\* Version 2.0 or higher.



#### Compatibility Data

If the bus node "Cube20 BN-P DP-V1 DI8" is operated with GDS file MUR20B3D.\*, it is not replaceable by predecessor model "Cube20 BN-P DI8".

The predecessor model "Cube20 BN-P DI8" is replaceable by bus node "Cube20 BN-P DP-V1 DI8", provided GDS file MURR0B3D.\* is used.

## 3.4 Baud Rates

All devices in a PROFIBUS network operate at a standard baud rate that is defaulted by the bus master. The Cube20 bus node automatically identifies the preset baud rate. Comply with the maximum permissible line lengths dependent on the baud rate used as shown in the table below. The values refer to one segment in each case. Larger network topologies are implementable across several segments by means of repeaters.

#### Maximum Permissible Line Lengths in a PROFIBUS Segment

Transmission speed in Kbps	9,6	19,2	45,45	93,75	187,5	500	1500	3000	6000	12000
Cable length in m	1200	1200	1200	1200	1000	400	200	100	100	100

Tab. 2: Cable lengths in a PROFIBUS segment

### 3.5 Configuration and Parameterization

The Cube20 system is usually configured with the help of a configuration tool provided by the master device manufacturer. The master sends the configuration telegram to the slave during system startup and defines the number of input and output bytes. Cube20 uses the special identifier format according to IED 61158. Cube20 can only be operated with DP masters that support the special identifier format.

On the basis of this information, the Cube20 bus node checks the installation for compliance with the projected configuration. If the bus node detects a difference between the nominal configuration transferred by the DP Master and the physical configuration, the bus node reports a configuration error message (parameter error message) and does not exchange data with the DP Master. A configuration or parameter error is displayed at the bus node by the LED "CFg F". If there is a failure, the LED "Cfg F" lights up red.

The Cube20 system is configured as a modular system. If supported by your DP master, the bus node "56001 BN-P DP-V1" is automatically added when the Cube20 bus node is entered. The bus node "56001 BN-P DP-V1" is always the 1st module in the configuration. It is capable of running without any expansion modules.

### 3.5.1 Example :Configuration of a Cube20 system with Simatic

#### Step7<sup>®</sup>

1

When GSD file MUR20B3D.\* is used, the hardware catalog of the Simatic Manager lists Cube20 BN-P DP-V1 DI8 Art. No.: 56001 under "Other Field Devices" and under "I/O" with the name "Cube20 BN-P DP-V1".




Fig. 3: Cube20 BN-P DP-V1 DI8 Art.No.: 56001 in the Simatic Manager

**2**

Mark "Cube20 BN-P DP-V1 DI8 Art. No. 56001" and drag the entry to the PROFIBUS string while keeping the left mouse button depressed, or double-click on the PROFIBUS string. This automatically adds the module "Cube20 BN-P DP-V1 DI8 Art. No.: 56001". In order to add additional modules to the configuration (max. 15), double-click on the corresponding entry in the hardware catalog.




Fig. 4: Adding Cube20 field units to the Simatic Manager



3

Double-click on any module to open a list box containing the parameter settings for this module.

Select the settings you require.




Fig. 5: Settings of Cube20 field units in the Simatic Manager

### 3.5.2 Cube20 BN-P DP-V1 DI8 Art. No. 56001

#### 3.5.2.1 Identification

Description	Art. No.	Process data		Identification
		Input	Output	
Cube20 BN-P DP-V1 DI8	56001	1 byte	0 byte	0x43, 0x00, 0xDA, 0xC1, 0x08

Tab. 3: Identification of Cube20 BN-P DP-V1 DI8 Art. No. 56001

### 3.5.2.2 Parameters

Number of parameter bytes: 6

Bit assignment of parameter Byte 0




Fig. 6: Parameter Byte 0 of Cube20 BN-P DP-V1 DI8 Art. No. 56001

Bit assignment of parameter Byte 1

Reserved

Bit assignment of parameter Byte 2

This defines whether actuator power supply diagnostics, such as undervoltage, or no voltage, are reported for the assigned slot or not.

- 0 = report
- 1 = do not report




Fig. 7: Parameter Byte 2 of Cube20 BN-P DP-V1 DI8 Art. No. 56001

**Bit assignment of parameter bytes 3 to 5**

This defines whether actuator power supply diagnostics, such as undervoltage, or no voltage, are reported for the assigned slot or not.

- 0 = report
- 1 = do not report

**Byte 3: Actuator power supply diagnostic for Slots 9 to 16**




Fig. 8: Parameter Byte 3 of Cube20 BN-P DP-V1 DI8 Art. No. 56001

**Corresponding assignment of Bytes 4 and 5:**

**Byte 4:**            **Actuator power supply diagnostic for Slots 17 to 24\***

**Byte 5:**            **Actuator power supply diagnostic for Slots 25 to 32\***

\* only when GSD file MUR20B3D.\* is used

**3.5.3 Cube20/67 Interface, Art. No. 56140**

When the GDS file MUR20B3D.\* is used, you also have the interface module "56140 Cube20/67 Interface" and several Cube67 modules at your disposal, besides the previous Cube20 modules available. Use of the interface module "56140 Cube20/67 Interface" before replacing a Cube20 module by a Cube67 module is optional, i.e. you are free to change directly from Cube20 to Cube67 (as in Fig. 9: 56221 after 56701), or to configure the interface module "56140 Cube20/67 Interface" (Fig. 10: ). The two configurations are valid.

Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	131		56221 - AO4 U/I		512...519
3	67		56701 AI4 E 4xM12 (U)	512...519	
4	195		56601 DI016 E 8xM12	1...2	0...1
5	195		56601 DI016 E 8xM12	3...4	2...3
6	195		56611 DI08 E 4xM12	5...6	4...5

Fig. 9: Configuration with Cube20 and Cube67 modules without interface module

Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	131		56221 - AO4 U/I		512...519
3	3		56140 - Cube20/67 Interface		
4	67		56701 AI4 E 4xM12 (U)	512...519	
5	195		56601 DI016 E 8xM12	1...2	0...1
6	195		56601 DI016 E 8xM12	3...4	2...3
7	195		56611 DI08 E 4xM12	5...6	4...5

Fig. 10: Configuration with Cube20 and Cube67 modules with interface module



**The configuration of a Cube20/Cube67 System may only include one interface module "56140 Cube20/67 Interface".**

### 3.5.4 Modules and Slots

Number of available slots	32*
Max. number of usable modules	16 (including bus nodes Cube20 BN-P DP-V1 DI8 Art. No. 56001, including interface module "56140 Cube20/67 Interface")*

\* only when GSD file MUR20B3D.\* is used

Too many modules are configured in the configuration in Fig. 11: . Since module 56140 "Cube20/67 Interface" is not considered in the calculation of the maximum number of modules, the error message "Slot 18: False Module" is issued, even if this configuration physically exists.

Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	131		56221 - AO4 U/I		512...519
3	67		56201 - AI4 U/I	512...519	
4	67		56240 - AI4 TH	520...527	
5	131		56117 - DO16 2A		0...1
6	3		56140 - Cube20/67 Interface		
7	67		56701 AI4 E 4xM12 (U)	528...535	
8	195		56611 DIO8 E 4xM12	1...2	2...3
9	131		56601 DO16 E 8xM12		4...5
10	131		56611 DO8 E 4xM12		6...7
11	67		56621 DI8 E 8xM8	3	
12	67		56631 DI8 E 4xM12 1A	4...5	
13	67		56603 DI16 E 8xM12	6...7	
14	67		56613 DI8 E 4xM12	8...9	
15	67		56623 DI8 E 8xM8	10	
16	131		56651xx DO16 E Valve		10...11
17	131		56655xx DO8 E Valve		12
18	131		56656xx DO32 E Valve 0,5A		13...16
19	131		56661 DO8 E Cable		17
20	195		56662 DIO16 E Cable	11...12	18...19
21	195		56663 DIO8 E M16 0,5A	13	20
22	195		56760 DIO4 RS485 E 3xM12	14...21	21...28

Fig. 11: Example of an incorrect configuration

Please note that the number of modules to be configured may be reduced if you deploy Cube67+ modules. For example, it is not possible to use more than six modules of type Cube67+ DIO12 IOL4 E 8xM12 Art. No. 56752, as they require five slots each: one slot for the module itself and four slots for virtual modules.

Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	3		56140 - Cube20/67 Interface		
3	195		56752 DIO12 E 8xM12 IO-Link	1...2	0...1
4	66		IOL_I_2 Byte	512...513	
5	2		IOL_DEACTIVATED		
6	2		IOL_DEACTIVATED		
7	2		IOL_DEACTIVATED		
8	195		56752 DIO12 E 8xM12 IO-Link	3...4	2...3
9	66		IOL_I_2 Byte	514...515	
10	2		IOL_DEACTIVATED		
11	2		IOL_DEACTIVATED		
12	2		IOL_DEACTIVATED		
13	195		56752 DIO12 E 8xM12 IO-Link	5...6	4...5
14	66		IOL_I_2 Byte	516...517	
15	2		IOL_DEACTIVATED		
16	2		IOL_DEACTIVATED		
17	2		IOL_DEACTIVATED		
18	195		56752 DIO12 E 8xM12 IO-Link	7...8	6...7
19	66		IOL_I_2 Byte	518...519	
20	2		IOL_DEACTIVATED		
21	2		IOL_DEACTIVATED		
22	2		IOL_DEACTIVATED		
23	195		56752 DIO12 E 8xM12 IO-Link	9...10	8...9
24	66		IOL_I_2 Byte	520...521	
25	2		IOL_DEACTIVATED		
26	2		IOL_DEACTIVATED		
27	2		IOL_DEACTIVATED		
28	195		56752 DIO12 E 8xM12 IO-Link	11...12	10...11
29	66		IOL_I_2 Byte	522...523	
30	2		IOL_DEACTIVATED		
31	2		IOL_DEACTIVATED		
32	2		IOL_DEACTIVATED		

Fig. 12: Example of a configuration using Cube67+ modules

### 3.6 I/O - Data Cube20 BN-P DP-V1 DI8 Art. No. 56001

#### Bit assignment I/O data - input data PAE

Byte 0								
Bit	7	6	5	4	3	2	1	0
Terminal	X2 03	X2 02	X2 01	X2 00	X1 03	X1 02	X1 01	X1 00

Tab. 4: Input Data Cube20 BN-P DP-V1 DI8 Art. No. 56001




# 4 Diagnostics

## 4.1 LED Indicators

 For a detailed description, please see the [Cube20 System Manual Art. No. 56030](#).

### 4.1.1 Significance of the States of the "Bus Run" LED

 The "Bus Run" LED represents the state of PROFIBUS communication on the [Cube20 BN-P DI8 Art. No. 56001](#).







Fig. 13: Bus-Run LED of Cube20 BN-P DI8 Art. No. 56001

LED Display	Response	State
	Lights up continuously	PROFIBUS-DP data exchange
	Flashing (green)	No PROFIBUS-DP data exchange
	Off	- PROFIBUS firmware not yet initialized - Voltage at terminal UB too low (<13V)

Tab. 5: LED-Bus-Run on Cube20 BN-P DP-V1 DI8 Art. No.: 56001

4.1.2 Significance of the States of the "Cfg F" LED



The "Cfg F" LED represents the state of a correct/incorrect configuration on the Cube20+ BN-P DP-V1 DI8 Art. No. 56001.






Fig. 14: Cfg F-LED on Cube20 BN-P DP-V1 DI8 Art. No. 56001

LED Display	Response	State
	Lights up continuously (red)	Real configuration does not match the projected configuration
	Off	Configuration correct

Tab. 6: Cfg F-LED on the Cube20 BN-P DP-V1 DI8 Art. No. 56001

### 4.1.3 Displays for the Supply Voltage at the Terminals



Please see the Cube20 System Manual Art. No. 56030.

### 4.1.4 Diagnostics Overview

Overview of the reported diagnostic messages Cube20 BN-P DP-V1 DI8 Art. No.: 56001

Designation of terminals	Description	Fieldbus Diagnostics	Related to:
UB	Undervoltage (< 18V)	Undervoltage	Modules
UI	Undervoltage (< 18V)	Undervoltage	Modules
US	Overload or short-circuit sensor supply	Short-circuit	Modules

Tab. 7: Overview of reported diagnostic messages

## 4.2 Diagnostics via the Fieldbus

There are a total of four levels of diagnostic information over PROFIBUS on the Cube20.

### 1. ProfiBus standard diagnostics

Bytes 0 to 5 of diagnostic telegram.

### 2. Identification-related diagnostic (information about what modules have a diagnostic function)

Bytes 6 to 10    Parameter Byte 0, Bit 1 = 0 (ID-related diagnostic is activated)

### 3. Module status diagnostic (information about what modules have a diagnostic function, or are missing, or are incorrect).

Bytes 11 to 22    Parameter Byte 0, Bit 2 = 0 (module status diagnostic is activated)

### 4. Channel-related diagnostic (short-circuits at outputs, etc.).

Byte 23....        Parameter Byte 0, Bit 1 = 0, Bit 2 = 0 (ID-related and module status diagnostics are switched on) 3 byte per channel, max. 64 channel diagnostics.



**When you set the bus node parameter "Diagnostic Message" to "Disable global diagnostics", the blocks "ID-related diagnostic" and "Module status diagnostic" still exist, but the content of these diagnostic blocks always indicate an errorfree state.**



**Use of the Profibus DP-V1 functionality Alarms and Status Reports for the diagnostic is not supported by Cube20 BN-P DP-V1 DI8 Art. No. 56001. Select Mode DP-V0 for the DP Alarm Mode (diagnostic mode) if the Profibus Master configuration tool offers an option.**



**All diagnostic messages are reported slot-dependent. Note here that some configuration tools name the first slot as Slot 0; others name it Slot 1. The reported diagnostic messages refer to the numbering of the first slot with "Slot 1".**

4.2.1 Standard Diagnostic Information Format

Standard diagnostic information Byte 0 to 5

Byte 0




Fig. 15: Standard diagnostic information Byte 0




Fig. 16: Standard diagnostic information Byte 1




Fig. 17: Standard diagnostic information Byte 2




Fig. 18: Standard diagnostic information Byte 3




Fig. 19: Standard diagnostic information Byte 4




Fig. 20: Standard diagnostic information Byte 5

4.2.2 Identification-Related Diagnostic

Identification-related diagnostic bytes 6




Fig. 21: Identification-related diagnostic Byte 6

Bit assignment of parameter bytes 7 to 10

Defines whether the assigned slot has an ID-related diagnostic.

Byte 7: Diagnostic of the ID for Slots 1 to 8:





Fig. 22: Identification-related diagnostic Byte 7

Corresponding assignment of Bytes 8 to 10:

- Byte 8        Slots 9 to 16
- Byte 9        Slots 17 to 24
- Byte 10       Slots 25 to 32



If you do not set the bus node parameter "ID-related diagnostic messages" to "Do not report", the block of ID-related diagnostics is no longer contained in the diagnostic telegram.



4.2.3 Module Status Diagnostic

Module status diagnostic Bytes 11 to 22

Byte 11

Module Status Diagnostic (Header Byte)




Fig. 23: Module status diagnostic Byte 11

Byte 12

Module Status Type




Fig. 24: Module status diagnostic Byte 12

Byte 13

Slot Number




Fig. 25: Module status diagnostic Byte 13

Byte 14

Status Specification




Fig. 26: Module status diagnostic Byte 14




Fig. 27: Module status diagnostic Byte 15

**Corresponding assignment of Bytes 16 to 22:**

<b>Byte 16:</b>	<b>Diagnostic of module status for Slots 5 to 8</b>
<b>Byte 17:</b>	<b>Diagnostic of module status for Slots 9 to 12</b>
<b>Byte 18:</b>	<b>Diagnostic of module status for Slots 13 to 16</b>
<b>Byte 19:</b>	<b>Diagnostic of module status for Slots 17 to 20</b>
<b>Byte 20:</b>	<b>Diagnostic of module status for Slots 21 to 24</b>
<b>Byte 21:</b>	<b>Diagnostic of module status for Slots 25 to 28</b>
<b>Byte 22:</b>	<b>Diagnostic of module status for Slots 29 to 32</b>



If you do not set the bus node parameter "Module status diagnostic messages" to "Do not report", the block of module status diagnostics is no longer contained in the diagnostic telegram.

4.2.4 Channel-Related Diagnostic

Channel-related diagnostic Bytes 23 to 25 and following

Three bytes are assigned in the diagnostic telegram for each channel-related diagnostic. If, for example, 5 channel-related diagnostics are available, a total of 5 times 3 bytes channel-related diagnostic information will follow from byte 23.




Fig. 28: Channel-related diagnostic Byte 23




Fig. 29: Channel-related diagnostic Byte 24

Byte 25								Fault Type	
7	6	5	4	3	2	1	0		
								Fault type	
								01hex (01dec)	Short circuit (in sensor supply)
								02hex (02dec)	I/O link undervoltage
								04hex (04dec)	Overload (sensor power supply)
								06hex (06dec)	Line break
								07hex (07dec)	Upper limit overshoot
								08hex (08dec)	Lower limit undershoot
								09hex (09dec)	Fault (e.g. I/O link)
								10hex (16dec)	Parameterization error
								11hex (17dec)	Actuator power supply undervoltage
								13hex (19dec)	Actuator power supply overload
								15hex (21dec)	Reference channel error
								17hex (23dec)	Actuator warning
								18hex (24dec)	Actuator disable
								1Ahex (26dec)	External fault
								1Bhex (27dec)	No actuator power supply
								1Chex (28dec)	No sensor power supply
								1Dhex (29dec)	No ext. actuator power supply
								1Ehex (30dec)	Ext. actuator power supply undervoltage
								Channel type	
								000 = reserved	
								001 = bit	
								010 = 2 bits	
								011 = 4 bits	
								100 = byte	
								101 = word	
								110 = 2 words	
								111 = reserved	

Fig. 30: Channel-related diagnostic Byte 25



If you set the bus node parameter "channel-related diagnostic messages" to "Do not report", no channel-related diagnostics are contained in the diagnostic telegram.

## 4.3 Troubleshooting



Rectify errors or incorrect modules in ascending slot order.

Diagnostic Message		Possible Cause	Action
Channel	Short-circuit (sensor supply)	Overload or short-circuit of sensor power supply to 0V.	Change cable to sensor or check sensor for short-circuit.
		Overload or short-circuit of internal system connection (channel type = 000)	Check cables on associated line.
	Undervoltage I/O link	I/O link undervoltage (events 0x5100 to x5119)	Check cable to sensor.
	Overload	Current load on a line greater than 4 A and less than 4.4 A (100 to 110%)	Check current load and possibly distribute to other lines.
	I/O link overload	I/O link overload (event 0x5410)	Check current load.
	Line break	Defective line. Only for analog inputs and outputs.	Check connection to sensor or sensor itself.
	Line break I/O link	I/O link device not plugged in or incorrect (invalid data length, cycle time too short, etc.)	Check connection to I/O link device. Check data length. Increase cycle time in parameters.
	Upper limit overshoot	Analog input measuring range overshoot.	Check connection to sensor or sensor itself.
	Upper limit overshoot (I/O link)	IO link event 0x8C10, 0x8C20	Check parameterization or measuring range.
	Lower limit undershoot	Analog input measuring range undershoot	Check connection to sensor or sensor itself.
	Lower limit undershoot (I/O link)	I/O link event 0x8C30	Check parameterization or measuring range.
	Fault	I/O link fault not assignable to another fault	Check I/O link devices or read out their event memories.
	Parameterization error	Parameterization incorrect.	Check parameterization.
	Actuator power supply undervoltage	Actuator power supply < 18 V	Check power supply unit and cable.
	Reference channel fault	TH module KTY not plugged in	Install KTY correctly.

Diagnostic Message		Possible Cause	Action
	Actuator warning	External power supply to an output.	Check cable.
	Actuator disable	Overload or short-circuit of output signal to 0V.	Check wiring or actuator.
	External fault	Desina diagnostic	Check sensor or wiring.
	No actuator supply	Actuator power supply < 13 V	Check power supply unit and cable.
	No sensor voltage	Sensor power supply < 13 V	Check power supply unit and cable.
	No ext. actuator power supply	External actuator power supply < 13 V	Check power supply unit and cable.
	Ext. actuator power supply undervoltage	Ext. actuator power supply < 18 V	Check power supply unit and cable.

Tab. 8: Troubleshooting

## 5 DPV1 Support Cube20 BN-P DP-V1 DI8

### Art. No. 56001

Cube20 BN-P DP-V1 DI8 Art. No. 56001 currently supports DP-V1 for each Master Class 1 and Master Class 2 access. Below is an overview of supported indices.

### 5.1 Supported DPV1 Indices

#### 5.1.1 Index 10 "Machine Options Management"





Fig. 31: Configuration test within the parameter list

Slots 2 to 32 can be enabled or disabled in 4 bytes, provided "Machine Options Management" is parameterized. Slot 1 (bus node) can not be disabled.



**Byte0 to Byte3 must always be written**

**Byte 0 Disable Slots 1 to 8:***Fig. 32: Assignment of Byte 0***Corresponds to:****Byte 1: Disable Slots 9 to 16:****Byte 2: Disable Slots 17 to 24:****Byte 3: Disable Slots 25 to 32:**

Placeholders may not be disabled If an attempt is made to do this, a configuration error is displayed.

Read/write requests in "Default Configuration" receive the negative reply "Feature not supported".

Read requests with "Machine Options Management" receive a positive reply. The response contains the parameters that were previously written with Index 10.

If the configuration is invalid, Index 10 write requests always receive a positive reply. If the configuration is valid after an Index 10 write request, every following Index 10 write request receives a negative reply with "State conflict".

If no valid configuration is set in "Machine Options Management", no "Static diagnostic" can be set in the system.





If "Machine Options Management" is set and there is still no valid configuration set, a diagnostic message "Missing module at Slot 1" is sent if the link to a module is lost. The system must be reset after the link problem is rectified.

If a further error occurs at Slot 1 in relation to the missing module, this error is NOT indicated in the default diagnostic but in the channel-specific diagnostic (see Fig. 33: Fig. 33: ).




Fig. 33: Error display in default and channel-specific diagnostic

For more details on "Machine Options Management", please refer to Chapter 6.

### 5.1.2 Index 12 "BusControl"

Byte 0 "BusControl":




Fig. 34: BusControl byte DPV1 Index 12

Use the BusControl request to perform a bus node reset from the PLC.

### 5.1.3 Index 13 "Machine Options Management Configuration Test"

Byte 0 Configuration test:




Fig. 35: Assignment of configuration test

Read request must be set with Index 13 to know whether a valid configuration was set in "Machine Options Management". Here, 1 is returned if the configuration is valid and the system is "OPERATIONAL", otherwise 0.

If the bus node is parameterized with "Default configuration"; the negative reply "Feature not supported" is sent.

Write requests receive a negative reply "Feature not supported".

### 5.1.4 Index 255 "Identification and Maintenance" (I&M)

The bus node itself supports a read request to I&M Index 65000 (IM0) and the manufacturer-specific Index 65100. If other Cube67+ modules are connected to the bus nodes, the Cube67+ modules can then support additional I&M indices. For more details, please refer to the related module documentation.

The bus node supports the following read/write requests:

Read bus node	IM0
Read bus node	IM100
Write Not-IOL module	IM100
Read Not-IOL module	IM100
Write IOL module	IM98
Read IOL module	IM98

#### 5.1.4.1 IM0 (65000)

Content	Size	Content
Header		
Manufacturer-specific	10 bytes	Manufacturer-specific
I&M data		
MANUFACTURER_ID	2 bytes	012Fhex, 303dec
ORDER_ID	20 bytes	'56001 '
SERIAL_NUMBER	16 bytes	' '
HARDWARE_REVISION	2 bytes	Manufacturer-specific
SOFTWARE_REVISION	4 bytes	Manufacturer-specific
REVISION_COUNTER	2 bytes	Manufacturer-specific
PROFILE_ID	2 bytes	F600hex
PROFILE_SPECIFIC_TYPE	2 bytes	0003hex
IM_VERSION	2 bytes	0101hex for V1.1
IM_SUPPORTED	2 bytes	0hex

Tab. 9: IM0

### 5.1.4.2 IM100 (65100)




Fig. 36: IM100 request to Cube20 BN-P DP-V1 DI8 Art. No. 56001 or Cube67 modules

Using the manufacturer-specific I&M Index 65100 (IM100), you can send read or write requests to module parameter bytes.



**If the outputs of an analog module are enabled or reparameterized by means of DP-V1 IM100 requests, the output data must be reset to 0 during the request. On completion of reparameterization, the output data are re-updated.**

## Example:

In the simple example below, we will show you how to disable a channel of an analog output module using two IM100 requests and enable another channel of the same module to switch a sensor off and switch another sensor on. The example was carried out using a Siemens controller. DP-V1 requests were handled using module that are available in the download section of the Murrelektronik website.

### The configuration:

Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	131		56220 - AO4 U/I		512...519

Fig. 37: Configuration example

Channel 0 of Cube20 module AO4 U/I Art. No. 56220 is enabled for the range 4 to 20 mA; here are the parameters in detail:

Station parameters	
Device-specific parameters	
Channel 0: output range	4...20mA
Channel 0: diagnostic	Report
Channel 0: data format	Byte seq. High/Low (Motorola)
Channel 1: output range	Inactive
Channel 1: diagnostic	Report
Channel 1: data format	Byte seq. High/Low (Motorola)
Channel 2: output range	Inactive
Channel 2: diagnostic	Report
Channel 2: data format	Byte seq. High/Low (Motorola)
Channel 3: output range	Inactive
Channel 3: diagnostic	Report
Channel 3: data format	Byte seq. High/Low (Motorola)
Hex parameter assignment	
User_Prm_Data (0 to 7)	03,00,00,00,00,00,00,00
User_Prm_Data (8 to 11)	00,00,00,00

Fig. 38: Example of parameters

The current parameter string of the module is 03 00 00 00 00 00 00 00 00 00 00 00; this can also be found in the parameter assignment of Cube20 AO4 U/I Art. No. 56220 (extract from the Cube20 Expansion Manual (Art. No. 56035):

Number of parameter bytes: 12

Bit assignment of parameter bytes 0 (Channel 0), 3 (Channel 1), 6 (Channel 2), 9 (Channel 3)




Fig. 39: Bit assignment of parameter bytes 0, 3, 6, 9

Bit assignment of parameter bytes 1, 2, 4, 5, 7, 8, 10, 11:

reserved

Disabling Channel 0 of Cube20 AO4 U/I Art. No. 56220

In order to change the module parameters using DP-V1, the DP-V1 Write Request is sent:

5F 02 FF 08 08 00 FE 4C A0 01 01 00

Meaning of the characters in detail (all hexadecimal):

5F	Write Request
02	Slot Number
FF	Number of index used (255dec = IM)
08	Number of useful data in bytes
08	Call Function
00	Reserved
FE 4C	(65100 dec) = IM100
A0 01	Index 20 01, here the highest bit is set (2+8 = A), it means write request
01	The 1st parameter byte (parameter byte 0) is handled
00	Write parameter for the selected byte

## Read Request

After the write request, a reply telegram is sent containing the written data length. According to the IM standard, this must be followed by a read request (without parameters).

### 5E 02 FF F0

Meaning of the numerals in detail (all hexadecimal):

5E	Read Request
02	Slot Number
FF	Number of index used (255dec = IM)
F0	Number of useful data in bytes

The parameter change was successful, Channel 0 is now set to "disabled".

## Enabling Channel 1 for the range 4 to 20 mA

The value 3 (binary 0000 0011) must be set for parameter byte 3. Here are the telegram data in detail:

**5F 02 FF 08 08 00 FE 4C A0 01 04 03**

Meaning of the numerals in detail (all hexadecimal):

5F	Write Request
02	Slot Number
FF	Number of index used (255dec = IM)
08	Number of useful data in bytes
08	Call Function
00	Reserved
FE 4C	(65100 dec) = IM100
A0 01	Index 20 01, here the highest bit is set (2+8 = A), it means write request
04	The 4th parameter byte (parameter byte 3) is handled
03	Write parameter for the selected byte

According to the IM standard, this must be followed by a read request (without parameters).

The parameter change was successful; Channel 1 is not enabled for the range 4 to 20 mA.



***STEP7 libraries that contain modules for IM accesses are available in the download section of the Murrelektronik website:***

***[www.murrelektronik.com](http://www.murrelektronik.com)***




## 6 Machine Options Management (MOM)

Using the Machine Options Management ("MOM"), you can perform a module configuration on machines. If the machine comprises a Basic Module A and an optional Machine Module B, for example, you can disable modules belonging to the – nonexistent – Machine Module B using Machine Options Management.

For this reason, the configuration tool configures all the optional modules of the Machine Module B modules. This configuration is then the "Maximum configuration". In addition, you can parameterize the "Configuration test" parameter of the bus node with "Machine Options Management". The system reports no error after runup and this is totally independent of the received configuration or parameterization. The bus node then reverts to data exchange, but the data are not yet updated.

In order to illustrate MOM, here is an example of maximum configuration:



Slot	DP ID	Order Number / Designation	I Address	Q Address
1	67	56001 BN-P DP-V1 DI8	0	
2	131	56220 - AO4 U/I		512...519
3	131	56221 - AO4 U/I		520...527
4	131	56118 - DO32		0...3
5	195	56168 - DI16 DO16	1...2	4...5


Fig. 40: Maximal configuration

### 6.1 Module Selection and Setting a Configuration

If the system is in data exchange mode, set the configuration you require by disabling the slots of the unused modules by means of DP-V1 Index 10 ("Machine Options Management"). You will find a detailed description of this in Section 5.1.1. A configuration text then takes place in the system, i.e. the configuration set using MOM is compared to the actual setup. If this test is OK, the configuration is valid and the system reverts to data exchange mode. If the test fails, the configuration is invalid and a diagnostic is generated (missing or false module). The system is then no longer in data exchange mode - the static diagnostic bit is set.

The test result can be requested using DP-V1 Index 13 ("Machine Options Management Configuration Test"). A detailed description of this is in Section 5.1.3. If the configuration is invalid, you can continue to try using MOM to set a valid configuration.

In our example, only the modules in Slots 1, 2, 4 and 5 are physically present. The module in Slot 3 is not present. It is then disabled by a DP-V1 write request using Index 10.



Slot	DP ID	Order Number / Designation	I Address	Q Address
1	67	56001 BN-P DP-V1 DI8	0	
2	131	56220 - A04 U/I		512...519
3	131	56221 - A04 U/I		520...527
4	131	56118 - D032		0...3
5	195	56168 - DI16 DO16	1...2	4...5

Fig. 41: Example of an invalid configuration

The physical setup does not comprise the module highlighted by the red border (Slot 3).

## Telegram parameters in detail:

### 5F 00 0A 04 04 00 00 00

Meaning of the numerals in detail (all hexadecimal):

- 5F Write Request
- 00 Slot number (Slot 1)
- 0 Number of index used (10dec)
- A
- 04 Number of useful data in bytes
- 04 1st parameter byte (parameter byte 0)
- 00 2nd parameter byte (parameter byte 1)
- 00 3rd parameter byte (parameter byte 2)
- 00 4th parameter byte (parameter byte 3)

### Bit pattern of parameter bytes:

Byte 1:

Bit value: 0 0 0 0 0 1 0 0 → Hex: 04  
 Slot number: 8 7 6 5 4 3 2 1

Byte 2:

Bit value: 0 0 0 0 0 0 0 0 → Hex: 00  
 Slot number: 16 15 14 13 12 11 10 9

Byte 3 and Byte 4 are also 0, as is Byte 2.



**A write request receives a positive reply telegram if it was successful, irrespective of the fact whether the configuration is valid or not.**

## 6.2 Configuration Test

A DP-V1 read request with Index13 can test whether the configuration is valid.

**Telegram parameters in detail:**

**5E 00 0D 01**

Meaning of the numerals in detail (all hexadecimal):

5E	Read Request
00	Slot Number
0D	Number of index used (13dec)
01	Number of useful data in bytes

If "Machine Options Management" is a default configuration, this results in a positive reply telegram that looks like this:

5E 00 0D 01 01 (configuration is valid and system is OPERATIONAL) or 5E 00 0D 01 00 (otherwise).

If the configuration is valid, the system reverts to data exchange mode. If there are diagnostics present, they are displayed, provided they were not disabled by bus node parameters.

If the configuration is invalid, the system does not revert to data exchange mode. Instead, the static diagnostic is set and a slot error is displayed.

Our example shows a valid configuration. The system is in data exchange mode.



**If a valid configuration is set, it is not possible to set another configuration using MOM. If you attempt to do this, it results in a negative reply telegram.**

In order to know which parameters were sent by Index 10, a read request can be made to Index 10 which returns the written parameters. If nothing was written, then zeros are returned.



**If the bit is set for a slot that does not exist (example: Slots 1 to 9 are assigned and Mask 00 00 02 00 was set (= Slot 18 is disabled), then this bit is ignored.**

## 6.3 Module Change

If you want to change modules, i.e. change the physical setup, this is the procedure:

1. **Switch off all power supplies of the bus node and all modules.**
2. **Replace the modules.**
3. **Switch on all power supplies of the bus node and all modules.**
4. **Set a valid configuration using Index 10.**
5. **Check whether the configuration is valid.**


### Example: Module Change

1. **Switch off power supplies of the bus node and all modules.**
2. **Replace the modules.**

Module 56220 is removed, Module 56221 is set at the same location.

3. **Switch on all power supplies of the bus node and all modules.**
4. **Set a valid configuration using Index 10.**

Now the modules of Slots 1, 3, 4, and 5 are connected; the module at Slot 2 is missing. It is disabled using DP-V1 Index 10 write request.



Slot	DP ID	...	Order Number / Designation	I Address	Q Address
1	67		56001 BN-P DP-V1 DI8	0	
2	131		56220 - AO4 U/I		512...519
3	131		56221 - AO4 U/I		520...527
4	131		56118 - DO32		0...3
5	195		56168 - DI16 DO16	1...2	4...5

Fig. 42: Example of module change

**Telegram parameters in detail:****5F 00 0A 04 02 00 00 00**

Meaning of the numerals in detail (all hexadecimal):

5F Write Request  
 00 Slot number (Slot 1)  
 0 Number of index used (10dec)  
 A  
 04 Number of useful data in bytes  
 02 1st parameter byte (parameter byte 0)  
 00 2nd parameter byte (parameter byte 1)  
 00 3rd parameter byte (parameter byte 2)  
 00 4th parameter byte (parameter byte 3)

**Bit pattern of 1st parameter byte:**

Byte 1:

Bit value:      0   0   0   0            0   1   0   0 → Hex: 02

Slot number:   8   7   6   5            4   3   2   1

**5. Check whether the configuration is valid.**

Now a test can be made using DP-V1 V1 read request by Index13 whether the configuration is valid. If this is the case, the system is in data exchange mode. The module change was successful.

## 7 Usable Modules

### 7.1 Cube20 Modules

All Cube20 modules are operable on the Cube20 BN-P DP-V1 DI8.



Please refer to the Cube20 System Manual for lists of the various Cube20 modules.

You will find a list of manuals in the section "List of Manuals and Layout" in this manual.

### 7.2 Cube67 Modules

All Cube67 modules are operable on the Cube20 BN-P DP-V1 DI8.



Please refer to the Cube67 System Manual for lists of the various Cube20 modules.

You will find a list of manuals in the section "List of Manuals and Layout" in this manual.

### 7.3 Cube67+ Modules

All Cube67+ modules are operable on the Cube20 BN-P DP-V1 DI8. The "+" of the Cube67+ stands for the expanded functionality of these modules.



Please refer to the Cube67+ Manual for the lists and information on the various Cube67+ modules.


You will find a list of manuals in the section "List of Manuals and Layout" in this manual.

## 8 Technical Data Cube20 BN-P DP-V1 DI8 Art. No. 56001

PROFIBUS Slave IP20 with 8 inputs

[Terminal X1] → 4 inputs

[Terminal X2] → 4 inputs



### EMC

#### EN 61131-2 Product standard

EN 61000-4-2 ESD .....	Contact $\pm 4$ kV, air $\pm 8$ kV
EN 61000-4-3 RF-Field & GSM .....	10 V/m
EN 61000-4-4 Burst .....	$\pm 2$ kV DC inputs, $\pm 1$ kV signal lines
EN 61000-4-5 Surge .....	Asym./symm. $\pm 500$ V
.....	Asym. $\pm 1$ kV
EN 61000-4-6 HF-asymmetric .....	10 V
EN 61000-4-8 Magnetic field 50 Hz .....	30 A/m
EN 55011 Emission .....	QP 40 dB $\mu$ V/m (30 - 230 MHz)
.....	QP 47 dB $\mu$ V/m (230 - 1000 MHz) Class A

### Ambient Conditions

Operating temperature .....	0°C... +55°C
Storage temperature .....	-20°C to +85°C
Enclosure type according to EN 60529 .....	IP 20

### Mechanical Ambient Conditions

Oscillation according to EN 60068 Part 2-6.....	5 g
Shock according to EN 60068 Part 2-27 .....	15 g / 11 ms

### Miscellaneous

Dimensions (LxWxH) in mm .....	117 x 56 x 47 mm
Mounting dimension (L x W) in mm .....	117 x 56 mm
Weight .....	Approx. 170 g

### Bus Data

Transfer protocol .....	PROFIBUS-DP according to IEC 61158 / 61784
Acyclic services.....	DP-V1 Master Class 1 and 2
Transfer rate.....	9,6 - 12000 kBaud
Baud rate identification .....	Automatically
Operating mode .....	Sync-Mode, Freeze-Mode are supported
Addressing.....	0 till 99 with BCD-rotary switch
Identity number .....	0B3D hex
Galvanic isolation.....	500 V between Bus and internal Logic

## System connection

Transfer protocol .....	Internal system
Addressing .....	Automatic

## Connection Possibilities

Internal system connection Out .....	10-pin male connector
Sensor and actuator supply .....	Cage clamp 2.5 mm <sup>2</sup>
Bus connection .....	Sub-D 9-pin
Sensor .....	2x4 terminal block connectors

## Power Supply

Operating voltage range logic $U_B$ .....	18 ... 30.2 V DC
Current consumption (only, $U_B$ ) .....	110 mA
Sensor supply $U_I$ .....	18 ... 30.2 V DC
Reverse voltage protection module electronics .....	Yes
Reverse voltage protection sensor power supply .....	yes
Overvoltage protection .....	yes (suppressor diode )

## Inputs

Delay time for signal change .....	2 ms
Input characteristics .....	EN 61131-2, Type 3
Galvanic separation .....	500 V

## Sensor power supply

Max. current .....	0.7 A
Short circuit protection for sensors with automatic restart .....	Yes
Reverse polarity protection .....	Yes



**This is a class A product. The product may cause broadcast interferences in a residential environment. In this case the applicant may have to take appropriate measures.**



## Accessories

A list of Cube20 accessories is contained in the Cube20 System Manual.



Information on accessories is available in our catalog and our online shop at:

[onlineshop.murrelektronik.com](https://onlineshop.murrelektronik.com)

## Glossary

Actuator shutdown	Short circuit or overload at an output leads to the shutdown
AI	Analog input
AO	Analog output
BN-P	Bus Node - PROFIBUS
Bus Run LED	LED that signals bus status
Bus segment	due to the electrical specification of the RS-485 interface, the number of users in an RS485 network is limited to 32. If there are more than 32 PROFIBUS users, the network must be divided into segments by means of repeaters.
1 byte	corresponds to 8 bits
Cfg F-LED	LED to signal a correct/incorrect configuration
DI	Digital input
DIN TH35	Standardized DIN rail (35x15mm, 35x7.5mm)
DO	Digital output
DP	Decentral Periphery. PROFIBUS protocol for rapid cyclical data exchange
E/A (I/O)	Input/output
EC Directive 2004/108/EEC	EMC Directive
EMC	Electromagnetic Compatibility
ESD	Electrostatic Discharge
FE	Function ground
Freeze Command	The input data of the slave are "frozen".
DDBF	The Device Master Data describes the technical features of a PROFIBUS product. This file is required to configure a PROFIBUS system and is provided by the device manufacturer.
I	Current
I/O	Input/ Output
ID number	A 16-bit number that identifies a PROFIBUS product uniquely. It represents a reference for the GSD file. Several devices have the same ID number, provided they are described in a common GSD file. This number is awarded by the PROFIBUS User Organization.
IEC 61158	Worldwide standard for PROFIBUS DP and FMS. Successor of international standard EN 50170, Volume 2

IP20	Ingress Protection, 20 = Device protection against the ingress of solid foreign bodies measuring a diameter of more than 12.5 mm (finger protection), the device is not protected against ingress of water with deleterious impacts.
LSB	Least Significant Bit.
FO	Optical fiber
MSB	Most Significant Bit.
Ni	Nickel
PAA	Process map of outputs
PAE	Process map of inputs
PELV	Protective Extra Low Voltage
PNO	Profibus Nutzerorganisation e.V. (German Profibus User Organization)
Power-LED	LED to signal the operating status
Pt 100	Temperature sensor on platinum base (0° is equivalent to 100Ω)
+R	High potential sensor connection
-R	Low potential sensor connection
Repeater	Coupling element to process signals between PROFIBUS segments
RL	Sensor power supply in three-wire mode
RTD	Resistance Temperature Device
S	Reference potential
SELV	Safety Extra Low Voltage.
Simatic Manager	Programming software for program-logic controllers made by Siemens
PLC	Program-logic controller
TH	Thermocouple
TH+	High potential sensor connection
TH	Low potential sensor connection
Type E, Type J, Type K, Type N, Type R	Thermocouples as per DIN EN 60584 standard
U	Voltage
U/I	Voltage / current
UA (brown terminal)	Actuator power supply
UA (red terminal)	Module power supply
UB	Operating voltage
UI (red terminal)	Module and sensor power supply
US (brown terminal)	Sensor power supply

---

VDMA	Verband Deutscher Maschinen- und Anlagenbau e.V. (Association of German Machinery and Industrial Equipment Manufacturers)
VZ	Sign
ZVEI	Zentralverband Elektrotechnik- und Elektronikindustrie e.V. (German Electrical and Electronic Manufacturers' Association)

## Legal Provisions

### Exclusion of Liability

Murrelektronik GmbH has checked the contents of this technical documentation for conformity with the hardware and software described therein. Deviations can not be excluded in individual cases. For this reason, Murrelektronik excludes the warranty for the correctness of its contents and any liability for errors, in particular full conformity. The limitation of liability shall not apply if the cause for damage is attributable to willful intent and/or gross negligence, or for all claims arising from the Product Liability Law. Should a major contractual obligation be violated by criminal negligence, the liability of Murrelektronik GmbH shall be limited to damages that typically arise.

Subject to technical changes and alternations in content. We advise that you check at regular intervals whether this documentation has been updated since corrections that may become necessary due to technical advances are included by Murrelektronik GmbH at regular intervals. We are gratefully for any suggestions for improvement.

### Copyright

It is prohibited to transfer or photocopy the documentation either in paper or in digital form, reuse or divulge its contents unless otherwise expressly permitted by Murrelektronik GmbH or in conjunction with the production of documentation for third-party products that contain products made by Murrelektronik GmbH. Violations will result in liability for damages. All rights reserved, in particular in the event of the award of patents or granting of utility models.

### Right of Use

Murrelektronik GmbH grants its customers a non-exclusive right revocable at any time and for an indefinite period of time to use this documentation to produce their own technical documentation. For this purpose, the documentation produced by Murrelektronik GmbH may be changed in parts, or amended, or copied, and transferred to the customer's users as part of the customer's own technical documentation on paper or on electronic media. The customer shall then bear sole responsibility for the correctness of the contents of the technical documentation produced by him.

If the technical documentation is integrated in part, or in full in the customer's technical documentation, the customer shall refer to the copyright of Murrelektronik GmbH. Furthermore, special attention shall be paid to compliance with the safety instructions.

Although the customer is obliged to make reference to the copyright of Murrelektronik GmbH, provided the technical documentation of Murrelektronik GmbH is used, the customer shall market and/or use the technical documentation on his sole responsibility. The reason is that Murrelektronik GmbH has no influence on changes or applications of the technical documentation and even minor changes to the starting product or deviations in the intended applications may render incorrect the specifications contained in the technical documentation. For this reason, the customer is obliged to identify the technical documentation originating from Murrelektronik GmbH if and inasmuch as the documentation is changed by the customer. The customer shall be obliged to release Murrelektronik from the damage claims of third parties if the latter are attributable to any deficits in the documentation. This shall not apply to damages to the rights of third parties caused by deliberate or criminal intent.

The customer shall be entitled to use the company brands of Murrelektronik GmbH exclusively for his product advertising, but only inasmuch as the products of Murrelektronik GmbH are integrated in the products marketed by the customer. The customer shall refer to the brands of Murrelektronik GmbH in an adequate manner if the brands of Murrelektronik GmbH were used.



*stay connected*

Murrelektronik GmbH | Falkenstraße 3, D-71570 Oppenweiler | P.O. Box 1165, D-71567 Oppenweiler  
Phone +49 7191 47-0 | Fax +49 7191 47-130 | [info@murrelektronik.com](mailto:info@murrelektronik.com) | [www.murrelektronik.com](http://www.murrelektronik.com)



The information in this manual has been compiled with the utmost care. Liability for the correctness, completeness and topicality of the information is restricted to gross negligence.